




1. Install frame square, level, plumb, and free of twist.




2. Screw down threshold at predrilled centers. Cover back of threshold extrusions, with timber cap. Fix negative load hook to sill.




3. To install bottom track, cut to length, then screw at 400mm centres, insure track is level, pack if needed.




4. Cut mortises into bottom of sliding panel along the centre line of the panel, to insert rollers into. Make smaller channel for access to adjustment screw.




5. Screw rollers into bottom rail. Ensure adjustment screws are facing outwards.




6. Mount top guides onto panel, along the centerline of the panel.




7. Pre Drill and CSK holes for 8g screws at 400mm centres, into top guide track.




8. Put track onto top guide, then lift and move door onto bottom track.



9. Fix interlocker with 8g screws.



10. Use adjustment screws to make door run level with the top and bottom tracks. Take the weight off the door while adjusting.







NOTES: Threshold kits

- 12010AL75 for 56mm thick doors.
- 12010AL63 for 44mm thick doors.
- 12010AL84 for 65mm thick doors.

Aluminium finishes Available (All anodized 20mic)

- (Suffix) A = Natural Anodized
- BRZ = Dark Bronze Anodized
- BLK = Black Anodized

		Recommended Hardware
2 Panel Stacker		2x Bottom Roller (#BR200T) 2x Top Guide (#BG1)  1x Guide Track (6m) (#TB5A) 1x Bottom Track  1x Interlocker (#12001A) 1x Threshold (#12000A) 1x Negative Load Hook Set (#12060LH)  <b>Track Lengths</b> • Bottom Track: 2.5m, 5m • Threshold: 2m, 4m • Interlocker: 2.5m, 5m
3 Panel Stacker		4x Bottom Roller (#BR200T) 4x Top Guide (#BG1)  2x Guide Track (6m) (#TB5A) 2x Bottom Track  2x Interlocker (#12001A) 1x Threshold Kit (#12010A) 2x Negative Load Hook Set (#12060LH)  <b>Track Lengths</b> • Bottom Track: 2.5m, 5m • Threshold: 2m, 4m • Interlocker: 2.5m, 5m
4 Panel Stacker		6x Bottom Roller (#BR200T) 6x Top Guide (#BG1)  2x Guide Track (6m) (#TB5A) 2x Bottom Track  3x Interlocker (#12001A) 2x Threshold Kit (#12010A) 3x Negative Load Hook Set (#12060LH)  <b>Track Lengths</b> • Bottom Track: 2.5m, 5m • Threshold: 2m, 4m • Interlocker: 2.5m, 5m
4 Panel		4x Bottom Roller (#BR200T) 4x Top Guide (#BG1)  1x Guide Track (6m) (#TB5A) 1x Bottom Track  2x Interlocker (#12001A) 1x Threshold (#12000A) 1x Negative Load Hook Set (#12060LH) 1x Negative Load Hook Set (#12060RH)  <b>Track Lengths</b> • Bottom Track: 2.5m, 5m • Threshold: 2m, 4m • Interlocker: 2.5m, 5m